

ApeosPort C2560/C2060 Operation Guide



Customer Contact Centre
400 820 5146

Copy

Select feature as requested, enter the number of copies, then tap on [Start].




Delete: Tap on [Pause] – [Delete].

Reset: Tap on [Reset] at the bottom of the Copy screen.





Scan (email, URL and PC)

Select recipients from [Favorites] or [Contacts], configure the settings as required, and tap on [Scan] / [Preview].






Print

Select [Print], select the printer and click [Printer Properties] to select the features, and then click [OK].



Scan to Folder


Select a folder to save the data, configure the settings as required and tap on [Scan]. Then download the document with "Stored File Manager 3" or CWIS.



FAX

Enter fax number by the keyboard or by tapping on the Address Book or Redial to specify the recipient.

Tap on [Done], and configure the setting items, then tap on [Send].





This document includes Fuji Xerox product, licensed from Xerox Corporation.
The distributor of the product is FUJIFILM Business Innovation Corp..